

ASNU Bio Clean 4 liter

Productcode: ASNU-bio-Clean
Beschikbaarheid: 3

Prijs: 149,00 €



Omschrijving

Reinigingsvloeistof voor in de intrasone injector reinigers

Deze vloeistof kan meermaals gebruikt worden tot u zelf merkt dat de werking vermindert.

Product galerij





Bio - Clean
Ultrasonic
Injector
Cleaning Fluid
QTY 5 Litres

Part No - ASNU 4i

WARNING: Do not inhale fumes from this product. Avoid contact with skin. If contact occurs, wash thoroughly with water. Do not use near open flames, hot surfaces or electrical equipment.

USE: For use in ultrasonic cleaning tanks. Add 200 ml of this fluid to the tank. Fill with water. Turn on the ultrasonic cleaner. Clean for 15-20 minutes. Drain the tank. Rinse the parts with water. Dry the parts.

SAFETY: Do not use near open flames, hot surfaces or electrical equipment. Do not use in confined spaces. Do not use in areas where there is a risk of fire or explosion. Do not use in areas where there is a risk of injury to persons or animals.

ASNU - International Support Unit
64-41 Queens Road, Bournemouth, Dorset, BH2 9DP England
Tel: +44 (0)1202 499 4444 Fax: +44 (0)1202 400 6662