

ASNU Bio Clean 4 liter

Productcode: ASNU-bio-Clean
Beschikbaarheid: 5

Prijs: 149,00 €



Omschrijving

Reinigingsvloeistof voor in de intrasone injector reinigers

Deze vloeistof kan meermaals gebruikt worden tot u zelf merkt dat de werking vermindert.

Product galerij





Bio - Clean
Ultrasonic
Injector
Cleaning Fluid
QTY 5 Litres

Part No. ASNU 4i

WARNING: ASNU 4i is a highly concentrated cleaning fluid. It is not intended for use on skin or clothing. It is highly flammable and should be stored in a cool, dry place away from heat and open flames. It should be kept in its original container and sealed tightly when not in use.

USE:
1. Dilute ASNU 4i with water in a 1:10 ratio.
2. Fill the ultrasonic cleaner with the diluted solution.
3. Turn on the ultrasonic cleaner and allow it to run for 15-20 minutes.
4. Turn off the ultrasonic cleaner and allow the solution to settle for 5 minutes.
5. Remove the parts from the solution and rinse them with clean water.

ASNU International Limited
64-67 Queens Road, Bournemouth, Dorset, BH2 9JQ England
Tel: +44 (0)1202 499 4444 Fax: +44 (0)1202 400 1992